

# Dockmaster Keyboard Assembly Guide

- 1.) Insert legs into couplers, keeping the offset of the couplers facing down towards the ground.



- 2.) Adjust to desired height to make an X and tighten retainer bolts-That's it with a KB1 with no extra arms. Set Canoe/ kayak/SUP atop the X



- 3.) Install arms KB2 (1 pair) and/or KB3 (2 pair) (if required or desired) by lifting each rack leg and sliding arms up on supports. Tighten arms at desired level to hold boards or kayaks according to height. Extra arms are available as a purchased option.



KB3 rack shown with 2 arms adjusted in water installation